

## M.2 (NGFF) WWAN modem USB breakout board - Bug #4231

connect /PERST line @NGFF to POWERGD (pin4 @X2)

10/17/2019 05:12 PM - mschramm

<b>Status:</b>	Resolved	<b>Start date:</b>	10/17/2019
<b>Priority:</b>	Normal	<b>Due date:</b>	
<b>Assignee:</b>	mschramm	<b>% Done:</b>	100%
<b>Category:</b>			
<b>Target version:</b>			
<b>Spec Reference:</b>			
<b>Description</b>			
Let's accept that there are some people who use POWERGOOD signal as a synonym for /PERST... This change finally made the breakout board successfully enumerated to a PCIe host when a PCIe-enabled WWAN card is loaded (tested with EM7565), so connect them.			

### History

#1 - 10/17/2019 05:13 PM - mschramm

- Assignee set to mschramm

#2 - 10/17/2019 06:37 PM - mschramm

- Status changed from In Progress to Resolved

- % Done changed from 0 to 100

done. - laforge wanted to have this signal remain on the pinheader too. To tame that resulting stub, a 33p cap was placed near the header.