

SIMtrace - Issues

| # | Tracker | Status | Priority | Subject | Assignee | Updated | Related issues |
|------|---------|--------|-----------|---|------------|---------------------|----------------|
| 1456 | Bug | Closed | Normal | make sure there is solder mask between pads of SAM7 | tsaitgaist | 02/20/2016 06:39 PM | |
| 1455 | Feature | Closed | High | try to improve trace width / blocking caps | tsaitgaist | 02/20/2016 06:39 PM | |
| 1454 | Feature | Closed | High | add "sysmocom" text into the copper layer | tsaitgaist | 02/20/2016 06:39 PM | |
| 1453 | Feature | Closed | High | Move C21 closer to VCC_SIM pad | tsaitgaist | 02/20/2016 06:39 PM | |
| 1452 | Bug | Closed | High | move C14 directly to pad 4 of IC2 | tsaitgaist | 02/20/2016 06:40 PM | |
| 1449 | Bug | Closed | High | no solder mask between the pads of the AT91SAM7 | tsaitgaist | 02/20/2016 06:41 PM | |
| 1448 | Bug | Closed | High | silk screen print on top of soldering pads | tsaitgaist | 02/20/2016 06:41 PM | |
| 1447 | Bug | Closed | High | C14 is too far from LDO, causes oscillation | tsaitgaist | 02/20/2016 06:41 PM | |
| 1446 | Bug | Closed | High | test ticket to check notification | tsaitgaist | 02/20/2016 06:41 PM | |
| 1445 | Feature | Closed | Low | Some component labels (resistors/capacitors) are not readable | tsaitgaist | 02/20/2016 06:41 PM | |
| 1444 | Feature | Closed | High | Adapt to different shottky diode footprint | tsaitgaist | 02/20/2016 06:41 PM | |
| 1443 | Feature | Closed | High | Adapt to different SPI flash (foot print) | tsaitgaist | 02/20/2016 06:42 PM | |
| 1442 | Feature | Closed | High | Make LED footprints 0805 instead of 0603 | tsaitgaist | 02/20/2016 06:42 PM | |
| 1441 | Feature | Closed | High | Use through-hole 2.5mm jack | tsaitgaist | 02/20/2016 06:42 PM | |
| 1440 | Feature | Closed | High | Use through-hole mini-USB-B socket | tsaitgaist | 02/20/2016 06:42 PM | |
| 1439 | Feature | Closed | Low | move ERASE and TEST jumper a tint bit, so a 1x4pin header works | tsaitgaist | 02/20/2016 06:42 PM | |
| 1437 | Bug | Closed | Immediate | on resistance of bus switch not acceptable, at least not for Vcc | tsaitgaist | 02/20/2016 06:42 PM | |
| 1436 | Feature | Closed | Normal | add VCC_PHONE to an unused GPIO | tsaitgaist | 02/20/2016 06:42 PM | |
| 1435 | Bug | Closed | Normal | sim card detect does not work (SW_SIM) | tsaitgaist | 02/20/2016 06:43 PM | |
| 1434 | Bug | Closed | High | socket for FPC SIM adapter is mechanically incompatible with rebelsim fpc | tsaitgaist | 02/20/2016 06:43 PM | |
| 1433 | Feature | Closed | Normal | use 90 degree angled jumpers for ERASE and TEST | tsaitgaist | 02/20/2016 06:44 PM | |
| 1432 | Bug | Closed | Normal | simtrace: bootloader switch without function | tsaitgaist | 02/20/2016 06:44 PM | |
| 1431 | Bug | Closed | High | use PA16 for UDP_PUP as required by SAM-BA | tsaitgaist | 02/20/2016 06:44 PM | |
| 1430 | Feature | Closed | Normal | clearly indicate location of 'pin 1' of components and connectors | tsaitgaist | 02/20/2016 06:44 PM | |
| 1429 | Feature | Closed | Normal | usb jack type is really hard to manually solder | tsaitgaist | 02/20/2016 06:44 PM | |
| 1428 | Feature | Closed | Normal | increase default trace width in simtrace pcb | tsaitgaist | 02/20/2016 06:44 PM | |
| 1427 | Bug | Closed | High | simtrace BC847 footprint has B / E switched | tsaitgaist | 02/20/2016 06:44 PM | |
| 1426 | Bug | Closed | Normal | simtrace component names on silk screen unreadable | tsaitgaist | 02/20/2016 06:44 PM | |
| 1425 | Bug | Closed | High | simtrace pinout of bootloader / reset switch is wrong | tsaitgaist | 02/20/2016 06:44 PM | |
| 1424 | Bug | Closed | High | simtrace pinout of tps73633 is wrong | tsaitgaist | 02/20/2016 06:45 PM | |